

Instructions: Patio Furniture Cover



Installation

Check your patio furniture to make sure there are no sharp objects or corners that could stress your cover as you pull it on. Use the handles located on either side of your cover to slip your cover over the top of your furniture then pull the



cover down on all four corners. Pull the cord located at the base of your cover to cinch the cover tight around your furniture. Wrap the click-it closures around your furniture legs and snap shut to secure your cover.

Cleaning and Care

Clean your cover with a soft brush and luke-warm water. DO NOT USE SOAP as it may remove the protective coatings added by the factory. Air dry.

Storage

To avoid any possibility of mildew be sure your cover is completely dry before you store

it in an enclosed area for a long period.

Three Year Warranty

This cover is factory warranted for workmanship and materials for three years after purchase.



**CLASSIC
ACCESSORIES**

WE COVER YOUR GEAR®

Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com

©2008

78912, 78932, 78952, 70992, 70922, 70932, 78922, 78942, 78962, 78972, 70912, 71932, 70952, 70962, 71972, 70972, 71982, 71992, 72912, 71962, 71912, 71922, 70942, 70982, 72922, 72932

o8cH55

Mode d'emploi: Housse pour mobilier de patio



Installation

Vérifiez votre mobilier de patio afin de vous assurer qu'il n'y a pas de bords ou d'objets pointus risquant d'étirer la housse lorsque vous tirez sur cette dernière.

Utilisez les poignées situées des deux côtés de la housse afin de passer la housse sur le dessus du mobilier puis tirez sur la housse vers le bas au niveau



des quatre coins afin qu'elle recouvre complètement le mobilier.

Tirez sur le cordon situé au bas de la housse afin de serrer la housse autour du mobilier.

Faites passer les sangles de fixation autour des pieds du mobilier et encliquez les fermoirs pour terminer l'installation.

Nettoyage et entretien

Nettoyez la housse à l'aide d'une brosse à soies douces et de l'eau tiède. NE PAS UTILISER DE SAVON car ceci risquerait d'endommager le revêtement protecteur qui a été ajouté en usine. Pour faire sécher la housse, accrochez-la sur une ligne de séchage ou placez-la dans le sèche-linge en réglant la machine sur « air » ou sur un cycle de séchage sans chaleur pour articles délicats uniquement.

Remisage

Pour éviter toute apparition de moisissure, assurez-vous que la housse est complètement sèche avant de la ranger dans un endroit fermé pour une longue période.

Garantie de trois ans

Cette housse est garantie par l'usine contre tout vice de matériau et de fabrication pendant une durée de trois ans à partir de la date d'achat.



**CLASSIC
ACCESSORIES**

WE COVER YOUR GEAR®

Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com

©2008

78912, 78932, 78952, 70992, 70922, 70932, 78922, 78942, 78962, 78972, 70912, 71932, 70952, 70962, 71972, 70972, 71982, 71992, 72912, 71962, 71912, 71922, 70942, 70982, 72922, 72932

o8cH55