HINKLEY
L I G H T I N G

Family: Cello | Item No. 4567 AT

▼ start here

Drawing 1 - Strap Detail

Ⓑ   Ⓑ
                  Ⓐ
GROUND SCREW
(top view)

Drawing 2 - Fixture Mounting

junction box
in ceiling

Ⓐ
        Ⓑ
    Ⓒ
Ⓓ   Ⓔ
        Ⓕ

Drawing 3 - Glass Installation

❶
❷
❸

1
1. Find a clear area in which you can work.
2. Unpack fixture and glass from carton.
3. Carefully review instructions prior to assembly.

*** *The construction of this fixture will be accomplished by first determining the length of stem required, mounting the mounting strap to the junction box, making all necessary electrical connections, hanging the fixture from the ceiling, and then installing the glass.*

2
1. Determine the overall length you will need the assembled fixture to be.

2. Determine what stems will be needed to achieve the overall length you require. (Additional stems are available and can be ordered. Ask your local Hinkley Lighting representative or visit www.hinkleylighting.com for information.)

3. Install stems by slipping them onto the supply wire of the fixture, threaded end up, and threading them together.

3
1. Prepare gem strap **(A)** for mounting by threading long two screws **(B)** not provided into back of gem strap **(A)** Note position of ground screw. - see **Drawing 1**.

• Be sure the holes into which the screws are threaded match the spacing of holes **(D)** in the canopy **(E)** - see **Drawings 1 and 2**.

2. Mount gem strap **(A)** to junction box **(J)**, using the two short screws **(C)** not provided.

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.

4
Make electrical connections from supply wire to fixture lead wires. Refer to instruction sheet **(I.S. 18)** and follow all instructions to make all necessary wiring connections. Then refer back to this sheet to continue installation of this fixture.

5
1. Hang the fixture by slipping the holes **(D)** in the canopy, over the screws **(B)** in the mounting strap - see **Drawing 2**.

2. Thread on ball knobs **(F)** to secure fixture to the ceiling.

6
1. To install glass, remove socket ring **(3)** from socket **(1)** - see **Drawing 3**.

2. Slip glass **(2)** over socket **(1)** and thread socket ring **(3)** back on to socket **(1)** to secure.

3. Fixture can now be lamped accordingly.

2.7.08

HINKLEY
L I G H T I N G

SAFETY WARNING: READ WIRING AND GROUNDING INSTRUCTIONS (I.S. 18) AND ANY ADDITIONAL DIRECTIONS. TURN POWER SUPPLY OFF DURING INSTALLATION. IF NEW WIRING IS REQUIRED, CONSULT A QUALIFIED ELECTRICIAN OR LOCAL AUTHORITIES FOR CODE REQUIREMENTS.

wiring instructions

Indoor Fixtures

1. Connect positive supply wire **(A)** (typically black or the smooth, unmarked side of the two-conductor cord) to positive fixture lead **(B)** with appropriately sized twist on connector - see **Drawings 1 or 2**.

2. Connect negative supply wire **(C)** (typically white or the ribbed, marked side of the two-conductor cord) to negative fixture lead **(D)**.

3. Please refer to the **grounding instructions** below to complete all electrical connections.

Outdoor Fixtures

1. Connect positive supply wire **(A)** (typically black or the smooth unmarked side of the two-conductor cord) to positive fixture lead **(B)** with appropriately sized twist on connector - see **Drawings 2 or 3**.

2. Connect negative supply wire **(C)** (typically white or the ribbed, marked side of the two-conductor cord) to negative fixture lead **(D)**.

3. Cover open end of connectors with silicone sealant to form a watertight seal.

• If installing a wall mount fixture, use caulk to seal gaps between the fixture mounting plate (backplate) and the wall. This will help prevent water from entering the outlet box. If the wall surface is lap siding, use caulk and a fixture mounting platform specially.

4. Please refer to the **grounding instructions** below to complete all electrical connections.

grounding instructions

Flush Mount Fixtures
For positive grounding in a 3-wire electrical system, fasten the fixture ground wire **(E)** (typically copper or green plastic coated) to the fixture mounting strap **(1)** with the ground screw **(2)** - see **Drawing 1**.
Note: On straps for screw supported fixtures, first install the two mounting screws in strap. Any remaining tapped hole may be used for the ground screw.

Chain Hung Fixtures
Loop fixture ground wire **(E)** (typically copper or green plastic coated) under the head of the ground screw **(2)** on fixture mounting strap **(1)** and connect to the loose end of the fixture ground wire directly to the ground wire of the building system with appropriately sized twist-on connectors - see **Drawing 2**.

Post-Mount Fixtures
Connect fixture ground wire **(E)** (typically copper or green plastic coated) to power supply ground with appropriately sized twist-on connector inside post. Cover open end of connector with silicone sealant to form a watertight seal - see **Drawing 3**.

Drawing 1 - Flush Mount

supply wire

(A) (C) (E)
+ −
1
2
+ −
(B) (D) twist-on connectors
fixture leads

Drawing 2 - Chain Hung

supply wire

(A) (C)
+ −
(E) twist-on connectors
1
(E) **2**
+ − (E)
(B) (D)
fixture leads

Drawing 3 - Post-Mount

supply wire

(A) (C)
+ −
(E) twist-on connectors
(E)
+ −
(B) (D)
fixture leads